







QUEENSTOWN HARBOR CHANNEL COORDINATES

LEFT SIDE		CENTERLINE			RIGHT SIDE	
Easting (X)	Northing (Y)	Station	Easting (X)	Northing (Y)	Easting (X)	Northing (Y)
1547380.84	488525.48	0+000.00	1547305.40	488459.84	1547229.96	488394.20
1548851.64	486834.97	22+36.07	1548773.23	486772.99	1548696.34	486708.97
1549786.29	485652.48	37+48.48	1549711.05	485586.44	1549635.79	485520.38
1550642.03	484774.99	49+96.53	1550582.43	484692.96	1550522.83	484610.88
1550300.65	483437.08	63+83.33	1550239.57	483349.21	1550196.95	483333.98
1550342.55	483319.98	70+70.33	1550793.15	482942.36	1550468.76	483134.19
1550815.37	482972.59				1550499.56	483049.49
					1550395.96	482908.49
					1550637.67	482730.89