



# NEAVITT HARBOR CHANNEL COORDINATES

|            | <u>STATION</u> | <u>EASTING (E)</u> | <u>NORTHING (N)</u> |
|------------|----------------|--------------------|---------------------|
| LEFT GEO   | 0+00.00        | 1518660.4          | 384847.0            |
|            | 2+49.84        | 1518894.5          | 384981.4            |
|            | 2+50.00        | 1519029.0          | 384747.3            |
|            | 2+80.52        | 1519065.0          | 384744.9            |
|            | 5+23.16        | 1519213.1          | 384827.7            |
|            | 20+66.67       | 1520825.2          | 384695.2            |
| CENTERLINE | 0.00+00        | 1518820.0          | 384569.0            |
|            | 4+42.46        | 1519203.2          | 384790.2            |
|            | 20+66.67       | 1520821.8          | 384655.3            |
| RIGHT GEO  | 0+00.00        | 1518844.6          | 384526.1            |
|            | 2+29.95        | 1519031.1          | 384633.2            |
|            | 2+50.00        | 1519047.1          | 384665.5            |
|            | 4+97.93        | 1519198.2          | 384750.2            |
|            | 20+66.67       | 1520818.5          | 384615.4            |